



INSTALLATION AND MAINTENANCE MANUAL

AUSTART ATS63I TURBINE STARTER



K.H. EQUIPMENT PTY. LTD.

14-16 WESTPOOL DRIVE,
HALLAM VICTORIA 3803 AUSTRALIA

PH: +61 3 8786 4766 FX: +61 3 9796 4878

EMAIL: info@khequipment.com.au WEB:

www.khequipment.com.au

NOTICE

THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. IT IS IMPORTANT THAT THE ENTIRE CONTENTS BE STUDIED BEFORE INSTALLATION AND OPERATION. IT ONLY REFLECTS GENERIC INFORMATION RELATING TO A STANDARD AUSTART ATS63I TURBINE STARTER. VARIOUS OTHER OPTIONS ARE AVAILABLE TO PROVIDE PRE ENGAGED DRIVE SYSTEMS, HARSH ENVIRONMENT MUFFLERS OR THREADED EXHAUSTS TO MEET SPECIFIC APPLICATION REQUIREMENTS.

FOREWORD

This manual contains instructions for the installation, maintenance and operation of your new ATS63I AUSTART Air Starter Motor. It has been designed to provide you with safe and reliable service. However, it is both a pressure vessel and a piece of rotating machinery. Therefore, operators and maintenance personnel must exercise good judgement and appropriate safety practices to avoid damage to the equipment and prevent personal injury. The instructions in this manual are intended for personnel with a general training in the operation and maintenance of air starter equipment. It should be understood that the information contained in this manual does not relieve the operating and maintenance personnel of the responsibility for exercising good normal judgement in the operation and care of air start equipment and their associated systems.

Throughout this manual you will encounter the words **WARNING**, **CAUTION** and **NOTICE**.

These paragraphs are intended to emphasise certain areas where personnel safety and satisfactory starter operation may be compromised should the message be ignored. The definitions of these words are as follows -



An operating procedure, practice etc. that if not strictly observed, could result in personal injury.

CAUTION

An operating procedure, condition etc. that if not followed could result in damage to, or the destruction of equipment.

NOTICE

An operating procedure, condition etc. that is essential to highlight and observe.

It is advisable that a safety program be established to address the safety issues detailed within this manual before installing, operating or maintaining this equipment. It is important such a program covers the hazards associated with compressed air.




Do not install this starter other than in accordance with the instructions detailed in this manual.

These instructions should be read completely before beginning installation and should be available to personnel responsible for operating and maintaining this equipment. The unit is capable of trouble free operation when properly applied, installed and maintained.

Extra copies of this manual are available from your local Austart Air Starter Distributor or the Factory.

This manual is designed to cover all situations normally experienced when installing, operating and maintaining this equipment. In the event situations are encountered that are not covered by this manual, consult your AUSTART agent or K.H. Equipment Pty Ltd direct.

AUSTART PRODUCT NUMBERING



MODEL PREFIX CODES: AS AUSTART VANE STARTER
ATS AUSTART TURBINE STARTER

		01	SAE 1	09	9TH 3MOD R	B	BCB (Beryllium Copper Bronze Pinion)
AS50	AUSTART AIR STARTER	02	SAE 2	10	10TH 8/10 R	E	Threaded Exhaust 1.5"
ATS53	AUSTART TURBINE STARTER	03	SAE 3	11	11TH 6/8 R	F	Threaded Exhaust 2" Bolt On
ATS54	(ATS53 OH) AUSTART TURBINE STARTER	04	SAE 4	12	12TH 8/10 R	G	Threaded Exhaust 2"
AS55	(AS50 OH) AUSTART AIR STARTER			13	12TH 8/10 L	H	Highway Special
AS61	AUSTART AIR STARTER			14	11TH 6/8 L	I	Inertia Drive
ATS63	AUSTART TURBINE STARTER		Other options	15	10TH 8/10 L	J	Threaded Exhaust Elbow 2"
ATS64	(ATS63 OH) AUSTART TURBINE STARTER		available	16	9TH 3MOD L	K	Kelly Spinner Muffler
AS66	AUSTART AIR STARTER					M	Mining Spec. (Cast Iron)
AS67	AUSTART AIR STARTER					N	Short Nose (Inertia ATS77)
AS68	(AS6070) AUSTART AIR STARTER				Other options	P	Motor Ports 90°
AS69	(AS67OH) AUSTART AIR STARTER				available	R	Reduced Muffler
AS70	AUSTART AIR STARTER					S	Short Muffler
ATS73	AUSTART TURBINE STARTER					T	Threaded Exhaust 3"
ATS77	AUSTART TURBINE STARTER					U	U Configuration
AS75	(AS70 OH) AUSTART AIR STARTER					V	Value Muffler (ATS77)
AS78	(AS7080) AUSTART AIR STARTER					X	Special – Refer Factory
AS80	AUSTART AIR STARTER						
ATS83	AUSTART TURBINE STARTER						
ATS84	(ATS83 OH) AUSTART TURBINE STARTER						
AS85	(AS80 OH) AUSTART AIR STARTER						
AS90	AUSTART AIR STARTER						
ATS93	AUSTART TURBINE STARTER						
ATS94	(ATS93 OH) AUSTART TURBINE STARTER						
AS95	(AS90 OH) AUSTART AIR STARTER						
AS100	AUSTART AIR STARTER						
ATS103	AUSTART TURBINE STARTER						
ATS183	AUSTART TURBINE STARTER						

EXAMPLES OF BASIC STARTER PRODUCT NUMBERING

ATS63-0110M	PERKINS 1006	SAE1	10TH	MINING SPEC
ATS63-0409M	MWM D916-6	SAE4	9TH	MINING SPEC
ATS73-0311	CUMMINS N14	SAE3	11TH	
ATS73-0314	CUMMINS N14	SAE3	11TH	LH
ATS73-0311I	DETROIT 12V71	SAE3	11TH	INERTIA DRIVE
ATS73-0314I	DETROIT 12V71	SAE3	11TH	INERTIA DRIVE LH
ATS73-0312M	CATERPILLAR 3306	SAE3	12TH	MINING SPEC
ATS83-0311IT	WAUKESHA 7072	SAE3	11TH	INERTIA THREADED EXHAUST

INSTALLATION AND PREPARATION FOR OPERATION



- Ensure air supply is isolated before installation, removal, maintenance or adjustment of your AUSTART starter.
- Before any starter is taken out of service first bleed the Air Receiver of air and any moisture that may have accumulated by opening up the drain valve. Do not bleed by removing Receiver plugs.
- Remove air hoses to ensure complete safety once the air supply has been isolated and the Receiver has been bled.
- The Air Receiver must be manufactured to an applicable pressure vessel code such as AS 1210, or similar.
- Only use air hoses and fittings that are of adequate size as indicated in the installation schematic (page 6)
- Always carry out a pressure test on the complete starting system according to Clause 7 on Page 5 before beginning operation. Do not begin operations until satisfied the unit has been installed correctly.
- Always use recommended lubricants where prescribed by this manual. Under no circumstances use flammable or volatile liquids.
- Ensure all fasteners are torqued to the values prescribed in this manual. Use thread sealant where indicated.
- To ensure warranty provisions are not invalidated use only genuine AUSTART replacement parts. Non-genuine parts may cause service and performance problems and may affect the safe operation of your starter.

PRELIMINARY INSTALLATION REQUIREMENTS

Numbers in Brackets refer to Part Nos, refer to exploded view drawing on page 8

1. Your Austart Starter is flange mounted. Before installing the starter carefully study the mating position of the Austart Starter and engine flanges to determine whether the air inlet port orientation or Nose Housing (36) geometry will suit your particular installation. If not suitable re-orientate as follows -
 - Carefully loosen the Band Clamp (9) but do not remove. The two housings can now be rotated relating to each other without separation.
 - Re-orientate the Housings to the desired position and torque the Band Clamp (9) to 4 ft lb (6 Nm)
2. Ensure pinion is suitable for engine application ie. correct pitch, diameter and number of teeth.
3. Check flange to ring gear (FRG) spacing is correct and that flange spacers are not required. Pinion should be FRG less 1/8" (3mm) when at rest.
4. Check Austart Starter clears all obstacles and the flange mounts to flywheel housing squarely without using undue force.
5. Ensure the hoses, fittings and starter ports are clean and free from dirt and foreign objects. Ensure they remain so during installation.
6. For optimum Austart Starter performance ensure air supply pipes or hoses have an internal diameter of at least 3/4" (19mm), refer Installation Schematic on page 6. In the event line length must be longer than 15ft (5m), a size of 1" (25mm) should be used. Keep the number of fittings and the length of piping to a minimum. Avoid the use of reducing bushes and other fittings that could impede air flow.

INSTALLING THE STARTER AND PIPEWORK

Refer to the Starter Installation Schematic drawing on page 6

1. The air supply line should ideally exit from the top or side of the Air Receiver.

CAUTION

Do not connect Air Supply Line to the bottom of the Air Receiver. Moisture and system contaminants collect at the receiver bottom and can damage the Austart Starter internals if allowed to pass through. Periodically drain moisture from the Air Receiver using a drain valve connected at the Receiver bottom.

2. Install a 100 mesh 'Y' Strainer. A 'Y' Strainer installed before the Relay Valve will provide protection to the Valve and Austart Starter from contaminants that may have accumulated in the Air Receiver.

NOTICE

Ensure the inlet side of the 'Y' Strainer faces the Receiver, ie the direction arrow points away from the Receiver.

3. Connect the RV1000 Relay Valve directly on to the 'Y' Strainer using a 1" Short Nipple.

NOTICE


Ensure the inlet side of the Relay Valve connects to the exit side of the 'Y' Strainer.

4. Mount the Starter Control Button SC25 onto the vehicle dash-board or appropriate control panel and connect to the Air Receiver using a minimum of 1/4" (6mm) line.

NOTICE

Ensure the inlet side of the Starter Control Button connects to the line from the Receiver. Any Safety "Switches" should be installed in this line between the Starter Control Button and the Air Receiver.

5. Determine the practicality of running the main air supply hose or pipe from the exit of the Relay Valve to the inlet of the Austart Starter after the Austart Starter is mounted. It may be easier to fit the hose before the Austart Starter is mounted in position.
6. Make all hose or pipe connections leak proof using a suitable thread sealant.
7. Once the connections have been made pressurise the system and check for leaks using "soapy" water or similar solution.




TITLE

SCALE: 1:3

DO NOT SCALE DRAWING

"This drawing is the property of K.H. Equipment Pty Ltd. It is intended for use for the specific purpose only and is not to be disclosed to anyone else or reproduced or used for manufacturing purposes without the express written permission of K.H. Equipment Pty Ltd."



FLANGE: SAE 1

TITLE

ATS631-General Arrangement


SCALE: 1:2

DO NOT SCALE
DRAWING

AUSTART

A3

"This drawing is the property of K.H. Equipment Pty Ltd.
It is furnished to you for confidential information purposes
only and is not to be disclosed to anyone else or
used in any way without the express written permission of K.H. Equipment Pty Ltd."



Exploded View
ATS63 - Inertia

TITLE

ATS631-Exploded View

SCALE: 1:20

DO NOT SCALE
DRAWING

AUSTART

A3

*This drawing is the property of K.H. Equipment Pty. Ltd.
It is furnished to you for confidential information purposes
only and is not to be disclosed to anyone else or used for
any other purpose without the express written permission of K.H. Equipment Pty. Ltd.

PARTS BREAKDOWN


AUSTART ATS-63I

General Build List

ITEM	PART NO.	EXT.	DESCRIPTION	QTY	ITEM	PART NO.	EXT.	DESCRIPTION	QTY
1	3029	000	NUT	3	29	6012	000	BEARING	1
2	6321	100	END COVER MUFFLER	1	30	6621	000	SEAL	1
3	6320	100	OUTER SLEEVE	1	31	6005	000	SCREW	6
4	3009	100	SPACER (0.624")	3	32	6326	100	GEAR ADAPTOR	1
5	6318	100	BAFFLE PLATE	1	33	6325	900	DRIVE SHAFT ASSY	1
6	3012	100	SPACER (1.050")	3	34	6016	000	DRIVE CIRCLIP	1
7	3027	100	STUD	3	35	6019	XXX	PINION HEAD	1
8	6319	100	BAFFLE SLEEVE	1	36	6728	XXX	NOSE HOUSING	1
9	6322	000	BAND CLAMP	2	37	6022	000	BEARING	1
10	6316	200	END COVER	1					
11	6323	000	O' RING	2					
12	6301	000	SPECIAL NUT	1					
13	6314	300	TURBINE ROTOR	1					
14	6302	920	TURBINE HOUSING	1					
15	6312	100	SEAL SLEEVE	1					
16	6313	000	PISTON RING	2					
17	6309	000	O' RING	2					
18	6310	000	BEARING	1					
19	6303	100	ROTOR SHAFT	1		6340	900I	SERVICE KIT	A.R.
20	6004	000	BEARING	1					
21	6308	000	CIRCLIP	1					
22	6617	000	CIRCLIP	1					
23	6305	000	COUNTERSUNK SCREW	3					
24	6306	100	RETAINER	1					
25	6307	100	PLANET GEAR	3					
26	6315	000	BEARING	3					
27	6311	900	SPIDER HUB ASSY	1					
28	6619	000	CIRCLIP	1					

-XXX DENOTES OPTIONS AVAILABLE

ATS63I/3 (A) Rev.01 31/07/08



Section View

ATS63 - Inertia

TITLE

ATS631-Section View

SCALE: 1:1

DO NOT SCALE
DRAWING

AUSTART

A3

"This drawing is the property of K.H.Equipment Pty Ltd.
It is furnished to you for confidential information purposes
only and is not to be disclosed to anyone else or
reproduced or used for manufacturing purposes without
the express written permission of K.H.Equipment Pty Ltd."

MAINTENANCE



DISASSEMBLY

Refer to the Cross Sectional and the Exploded View drawings on pages 8 & 10

Begin by removing the two Band Clamps (9) and separate the three Sub-Assemblies; the Nose Assembly, the Motor Assembly and the Silencer Assembly. Gently tap the assemblies with a soft hammer if necessary.

The Sub-Assemblies may now be dismantled separately. Disassembly of any of these three Sub-Assemblies is detailed in the exploded view on page 8 and is basically in the order shown. Refer also to the following instructions:

Nose Assembly

1. Remove six Screws (31) and separate the Gear Adaptor (32) from the Nose Housing (36).
2. Remove Drive Circlip (34) from Pinion head (35).
3. Invert Bearing Housing assembly and retain Drive shaft assembly (33) using soft jaws in a vice.
4. Remove the three countersunk screws (23) which may require a sharp tap to loosen them.
5. Remove Retainer (24), Planet Gears (25) and Bearings (26).
6. Support Gear Adaptor (32) in the vertical position, remove Circlip (22) using circlip pliers and gently press out Drive Shaft assembly (33) from Spider Hub (27) and Bearing (29).
7. Remove Circlip (28) using circlip pliers and press out Bearing (29) and Seal (30).
8. Remove Nose Bearing (37) from Nose Housing (36).

Motor Assembly

1. Remove Special Nut (12) by holding Rotor Shaft (19) with the two flats provided in a vice.

CAUTION

Do not hold Rotor Shaft by splined end when removing Special Nut. Damage to spline will cause premature Gearbox failure.

2. Remove Circlip (21) using circlip pliers and press out Rotor Shaft (19) through Rotor (13) as an Assembly.
3. Press out Seal Sleeve (15) and Bearing (18) from Turbine Housing (14).
4. Press off Bearing (20) from the Rotor Shaft (19).

Silencer Assembly

Remove the three Nuts (1) and Assembly will easily come apart.

INSPECTION

Refer to the Cross Sectional and the Exploded View drawings on pages 8 & 10

1. Visually inspect all parts removed during disassembly for excessive wear or damage. Replace any damaged or questionable parts.
2. Pay particular attention to the vanes on End Cover (10) and Turbine Rotor (13) and look for cracks, chipping, warpage or excessive wear patterns. Rotor (13) should fit tightly on to the Rotor Shaft (19). Replace any damaged or questionable parts. Remove burrs.
3. Also pay particular attention to all gear teeth looking for cracked or broken teeth and excessive wear. Check the pinion head (35) for evidence of unusual contact patterns resulting from misalignment or improper engagement. Remove any burrs or replace if questionable.
4. Check all bearings are free to rotate and do not have excessive play between races. If in doubt replace questionable bearings.

CAUTION

Do not wash shielded bearings that are to be reused in solvent or blow with compressed air as it may remove internal lubrication. Bearings that are to be reused should be cleaned by wiping the end shields with a clean cloth.

5. Clean all other parts that are going to be reused with commercially approved solvents.



Ensure cleaning operations are carried out in a properly vented area away from open flames.

6. It is recommended that when servicing your Austart Turbine Starter always replace complete repair kit contents.

REASSEMBLY

Refer to the Cross Sectional and the Exploded View drawings on pages 8 & 10

Reassembly of any of the three Sub-Assemblies detailed in the exploded view on *page 8* is basically in the reverse order shown. Refer also to the following instructions:

Nose Assembly

1. Begin by pressing the Bearing (37) into Nose Housing (36) using a press with an appropriate pressing tool.
2. Drive home the Seal (30) into the Gear Adaptor (32) until it bottoms.

CAUTION

Ensure the Seal (30) is fitted the correct way, ie with the tapered leading edge engaged first. Liberally grease the exposed side of the Seal (30) with Lithium based grease such as Valvoline VALPLEX EP Grease or similar.

3. Using a press drive home the Bearing (29) into the Gear Adaptor (32) until it bottoms. Then insert Shaft (33) into the Bearing (29) and press home. Ensure the Gear Adaptor (32) and Bearing (29) are well supported during this operation. Finally fit Circlip (28) using circlip pliers.
4. Invert the Gear Adaptor (32) and restrain in the vertical position. Slip on Spider Hub Assembly (27) onto Shaft (33) and fit Circlip (22) using circlip pliers.
5. Restrain Drive Shaft Assembly (33) in vice using soft jaws.
6. Install the three Planet Gears (25) and Gear Bearings (26) onto the Spider Hub Assembly (27).

CAUTION

Ensure Planet Gears are installed with the boss side of the Gear facing the Spider Hub. Coat Gear Bearings with Grease before Assembly.

7. Fit Retainer (24) to the Spider Hub Assembly (27) and install the three Countersunk Screws (23).
8. Invert Gear Adaptor assembly and insert Pinion Head (35) onto Drive Shaft assembly (33). Insert Drive Circlip (34) into Pinion Head (35) making certain that it is fitted correctly.
9. Liberally coat Nose Bearing (37) with grease and assemble Nose Housing (36) on to Gear adaptor assembly insert the six screws (31).
10. Liberally pack gear teeth with suitable grease such as Valvoline Valplex EP or similar.
11. The Nose Assembly is now ready to accept the Motor Assembly.

1. Begin by lightly oiling the internal bore of the Turbine Housing (14) with hydraulic oil and fitting inner O-Ring (17).
2. Evenly press home Bearing (18) until it bottoms. Ensure O-Ring (17) is not damaged or dislodged.
3. Install Piston Rings (16) onto Seal Sleeve (15). Rotate Piston Rings (16) so that the gaps are 180° apart.
4. Lightly grease the outside of the Piston Rings (16) on the Seal Sleeve (15) and push home into the Turbine Housing (14) until it bottoms.
5. Press Bearing (20) onto Rotor Shaft (19) using a press and liberally grease top of bearing.
6. Install 2nd O-Ring (17) into Turbine Housing (14) and insert Rotor Shaft (19) and Bearing (20) as an assembly. This should be achieved with an even push fit.
7. Install Circlip (21) with circlip pliers.
8. Fit Turbine Rotor (13) onto Rotor Shaft (19) extension. As this is an interference fit it is necessary to warm the Turbine Rotor (13) with a heat gun or boiling water before installing.
9. Lightly oil thread on Rotor Shaft (19) extension and install Special Nut (12). Tighten Nut against the Turbine Rotor (13) to a torque of 25-30 ft lb.(30-40 Nm). Prevent the Rotor Shaft (19) from turning by holding the flats provided on the Rotor Shaft (19) in a vice.

CAUTION

Do not hold Rotor Shaft by splined end when installing Special Nut as damage can occur.

Assemble in the reverse order of disassembly. Ensure Baffle Plates and Spacers are in correct positions. Tighten nuts (1) firmly.

Assembling Nose and Motor Assemblies

1. Apply grease to Planet Gears (25) and Gear Case (32). Carefully line up spline of Motor Assembly Shaft (19) with the Planet Gears (25) on the Nose Assembly and slide the Nose Assembly home.
2. Line up the Nose Assembly and Motor Assembly and install Band Clamp (9). Tighten Band Clamp (9) to 4 ft lb (6 Nm).
3. The Nose/Motor Assembly is now ready to accept the Silencer Assembly.

Adding Silencer Assembly

1. Install Silencer Assembly to the Turbine Housing (14). Install Band Clamp (9). Tighten Band Clamp (9) to 4 ft lb (6 Nm)
2. The Austart Air Starter is now assembled and ready for installation. Refer Installation and Operation section of this manual.

WARRANTY POLICY

All Austart Products supplied by K.H. Equipment Pty. Ltd. (herein called “the Manufacturer”) is warranted to be free from any defect in workmanship and material under conditions of normal use and service for engine starting applications for a period of 12 months from the date of purchase by the first user. Normal wear and tear is excluded from the warranty cover.

The Manufacturer will replace or repair at their works, without cost, any Austart Starter or parts found to be defective or at their discretion choose to refund the purchase price less a reasonable allowance for depreciation in exchange for the starter or part should the item prove impossible to repair or replace.

This warranty shall not apply to any Austart Starter or parts which have been altered or repaired or purchased outside the Manufacturer and its assigned agents nor to equipment or parts that have been subject to misuse including overloading, neglect, accident or damage, nor to any part or parts improperly applied or installed.

This warranty is in lieu of all other warranties and conditions statutory or otherwise expressed or implied and of all other obligations or liabilities on the Manufacturer’s part. The Manufacturer’s maximum liability is limited to the purchase price of the starter and is not liable for any consequential damage, loss or expense.

Repeat engine starting attempts must be delayed for 15 seconds to allow all Austart Starter and engine components to stop rotating to avoid damage or adverse wear of components.

This image shows a full page of blank white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page, providing a template for writing or drawing. There are no margins, text, or other markings present.

--